Canon

PUB. DIE-0447-000 0175W481

DIE0447000

HD Camcorder

LEGRIA mini Getting Started

Package Contents

- ☐ HD Camcorder LEGRIA mini
- ☐ NB-4L Battery Pack [①]
- ☐ CB-2LVE Battery Charger [②]
- ☐ IFC-400PCU USB Cable [③]
- ☐ WS-DC11 Wrist Strap [④]
- ☐ LEGRIA mini CD-ROM



1 Installing the Camcorder's Instruction Manual (PDF File)

This guide only introduces the most basic functions of the camcorder to get you started. To learn more about your camcorder, to read important handling precautions and to consult the troubleshooting section if an error message is displayed, be sure to read the full-version Instruction Manual (PDF file).
You can install the PDF Instruction Manual on a computer using the following procedure. The most up-to-date version of the PDF file is also available for download on your local Canon Web site. This may be more convenient if you prefer to have the PDF file available on your smartphone or tablet.

1. Turn on the computer.
2. Insert the LEGRIA mini CD-ROM into the computer's disc drive.
3. **Windows:** Use Windows Explorer to open the drive into which you inserted the CD-ROM.
   Mac OS: Use Finder and click the CD-ROM icon.
4. Click/Double-click the **Disc_Setup** icon.
5. In the installer panel, click [Instruction Manual of the Camcorder] and select your language.
   - Windows users: If a User Account Control dialog box appears, follow the instructions.
6. When the installation is complete, click [OK], then [Exit].
   - The installer will save the camcorder's Instruction Manual (PDF file) on the computer and will create a shortcut icon on the desktop for easy access.

2 Charging and Installing the Battery Pack

Charge the supplied battery pack in advance, using the supplied battery charger. Fully charging the supplied battery pack will take about 1 hour 30 minutes.

1. Attach the battery pack to the battery charger, aligning the triangle marks.
2. Connect the power cord to the battery charger and plug the other end into a power outlet.
   - The CHARGE indicator lights up in orange. When the CHARGE indicator on the battery charger turns green, the battery pack is fully charged.



3. Unplug the power cord and disconnect it from the battery charger, and remove the battery pack.
4. Open the camcorder's battery compartment cover, insert the battery pack and close the cover.



3 Inserting a Memory Card

You can use commercially available microSD, microSDHC and microSDXC cards with this camcorder. We recommend using memory cards rated SD Speed Class 10. Initialize a memory card using the [Complete Initialization] option before using it with the camcorder for the first time (PDF Initializing a Memory Card).

1. Make sure the camcorder is off.
2. Open the memory card slot cover and insert the memory card with the label side facing up.



3. Close the memory card slot cover.

4 Basic Setup

The first time you turn on the camcorder, you will be guided by the camcorder's basic setup screens to select the camcorder's language and set the date and time.

1. Turn on the camcorder.
2. Touch the desired language for onscreen displays and then touch [▷].
3. Touch the desired date/time format and then touch [▷].
4. Set the date and time.
   - Touch a field you want to change and touch [▲] or [▼] to change. Repeat as necessary.
   - Touch [24H] to use 24-hour clock or leave untouched to use AM/PM.
5. Touch [OK] to complete the basic setup and close the setup screen.



5 Adjusting the Camcorder

You can adjust the angle of the articulated LCD panel and the built-in stand. Change the position of the camcorder as necessary to match your shooting style.



6 Shooting Video and Taking Photos

1. Turn on the camcorder.



2. **Video:** Touch [●] to start recording video. Touch [■] to stop recording.



Photos: Press the photo button to record a photo.



3. When you finish recording, turn off the camcorder.

7 Playing Back Video and Viewing Photos

1. Press the ▶ button.
   - The [▶] index screen will open. To view photos, touch [🏠] ❯ [📷 Photo Playback] to open the [📷] index screen.



2. Touch the thumbnail of the scene or photo you want to play back.
   - During playback, touch the scene to display the playback controls.

To delete recordings

From the index screen:

1. Touch [Edit] ❯ [Delete].
2. Select whether to delete all the scenes/photos in the same folder, selected scenes/photos, or all scenes/photos.
   - To select individual recordings: touch all the scenes/photos you wish to delete to mark them with a ☑, then touch [OK].
3. Touch [Yes] ❯ [OK].

Downloaded From VideoCamera-Manual.com Manuals

Wi-Fi Functions

The camcorder features a number of convenient Wi-Fi functions that will allow you to use it in combination with Wi-Fi enabled smartphones and tablets. For example, you can use a smartphone or tablet to control the camcorder remotely while recording or to upload recordings to the Web.

1. If necessary, install the required app on the smartphone or tablet.
2. Select the desired Wi-Fi function on the camcorder.
3. Wirelessly connect the device to the LEGRIA mini.

Note: The necessary procedure may differ according to the Wi-Fi function you wish to use. For details, be sure to refer to the PDF Instruction Manual (PDF Wi-Fi Functions).

Optional Accessories

Canon offers a wide range of optional accessories for your camcorder. For details, be sure to refer to the PDF Instruction Manual (PDF Optional Accessories).

Use of genuine Canon accessories is recommended.
This product is designed to achieve excellent performance when used with genuine Canon accessories. Canon shall not be liable for any damage to this product and/or accidents such as fire, etc., caused by the malfunction of non-genuine Canon accessories (e.g., a leakage and/or explosion of a battery pack). Please note that this warranty does not apply to repairs arising out of the malfunction of non-genuine Canon accessories, although you may request such repairs on a chargeable basis.

This mark identifies genuine Canon video accessories. When you use Canon video equipment, we recommend Canon-brand accessories or products bearing the same mark.

Important Usage Instructions

COPYRIGHT WARNING:
Unauthorized recording of copyrighted materials may infringe on the rights of copyright owners and be contrary to copyright laws.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO LOCAL REGULATION.

Only for European Union and EEA (Norway, Iceland and Liechtenstein)

These symbols indicate that this product is not to be disposed of with your household waste, according to the WEEE Directive (2012/19/EU), the Battery Directive (2006/66/EC) and/or national legislation implementing those Directives.
If a chemical symbol is printed beneath the symbol shown above, in accordance with the Battery Directive, this indicates that a heavy metal (Hg = Mercury, Cd = Cadmium, Pb = Lead) is present in this battery or accumulator at a concentration above an applicable threshold specified in the Battery Directive.
This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE) and batteries and accumulators.
Improper handling of this type of waste could have a possible impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources.
For more information about the recycling of this product, please contact your local city office, waste authority, approved scheme or your household waste disposal service or visit www.canon-europe.com/weee, or www.canon-europe.com/battery.

Complies with IDA Standards DB007671

This product is installed with the WLAN Module which is certified to standards set by IDA Singapore.

Precautions About the Battery Pack

DANGER!

Treat the battery pack with care.

- Keep it away from fire (or it might explode).
- Do not expose the battery pack to temperature higher than 60 °C. Do not leave it near a heater or inside a car in hot weather.
- Do not try to disassemble or modify it.
- Do not drop it or subject it to shocks.
- Do not get it wet.

Important Note About the Memory Card

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss or damage to the memory card.
  - Do not remove the memory card.
  - Do not disconnect the camcorder's power source or turn off the camcorder.
  - Do not press the ▶ button.

REGIONS OF USE

The LEGRIA mini is in compliance (as of June 2013) with the radio signal regulations of the regions listed below. For details on other regions where it can be used, make inquiries with the contacts listed inside the blue frame at the bottom of this page.

REGIONS

Australia, Austria, Belgium, Bulgaria, China (PRC mainland), Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hong Kong S.A.R., Hungary, Iceland, Ireland, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Malta, Netherlands, New Zealand, Norway, Poland, Portugal, Romania, Russia, Singapore, Slovakia, Slovenia, Spain, Sweden, Switzerland, United Kingdom

Statement on EC directive

CE

Hereby, Canon Inc., declares that this RF401 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Please contact the following address for the original Declaration of Conformity:
CANON EUROPA N.V.
Bovenkerkerweg 59, 1158 XB Amstelveen, The Netherlands
CANON INC.
30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan

Model
ID0033: LEGRIA mini

Trademark Acknowledgements

- microSD, microSDHC and microSDXC Logos are trademarks of SD-3C, LLC.
- Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.
- Mac OS is a trademark of Apple Inc., registered in the U.S. and other countries.
- Wi-Fi is a registered trademark of the Wi-Fi Alliance.
- Wi-Fi Certified, WPA, WPA2, and the Wi-Fi Certified logo are trademarks of the Wi-Fi Alliance.
- Other names and products not mentioned above may be trademarks or registered trademarks of their respective companies.
- This device incorporates exFAT technology licensed from Microsoft.
- "Full HD 1080" refers to Canon camcorders compliant with high-definition video composed of 1,080 vertical pixels (scanning lines).
- This product is licensed under AT&T patents for the MPEG-4 standard and may be used for encoding MPEG-4 compliant video and/or decoding MPEG-4 compliant video that was encoded only (1) for a personal and non-commercial purpose or (2) by a video provider licensed under the AT&T patents to provide MPEG-4 compliant video. No license is granted or implied for any other use for MPEG-4 standard.

Canon Inc. 30-2 Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, JAPAN

Canon Europa N.V.
Bovenkerkerweg 59, 1185 XB Amstelveen, The Netherlands
www.canon-europe.com

Canon UK Ltd
CCI Service Centre, Unit 130
Centennial Park, Borehamwood, Hertfordshire, WD6 3SE, United Kingdom
Telephone 0844-369-0100

Canon Australia Pty Ltd
Tel: 13-13-83 (within Australia only)
(61) 02-9805-2555
www.canon.com.au

Canon New Zealand Ltd
Tel: 0800-222-666 (within New Zealand only)
(64) 09-489-0300
www.canon.co.nz

Canon Singapore Pte. Ltd
1 HarbourFront Avenue, #04-01 Keppel Bay Tower, Singapore 098632
Tel: (65) 6799 8888
Fax: (65) 6799 8882

Canon Hongkong Company Ltd
19/F, The Metropolis Tower, 10 Metropolis Drive, Hunghom, Kowloon, Hong Kong
Tel: +852 3191 2333, Fax: +852 2428 3963

Canon Latin America, Inc.
Sales & Enquiries:
One Canon Park, Melville, NY 11747 USA

The information in this guide is verified as of June 2013. Specifications and outer appearance are subject to change without previous notice.

© CANON INC. 2013

Downloaded From VideoCamera-Manual.com Manuals